



Trouble Shooting Sticking issues with SilcSkin Pads

The pads are to be worn on **clean dry skin** with absolutely no product or lotions underneath, this interferes with the adhesive quality as well as can cause rashes and reactions. If the Pads are placed over skin that is moist or has product in the chest wrinkles, and not pressed down properly will possibly create a rash and suction marks along those wrinkles.

Also, night sweats, hot flashes and perspiration will interfere with the adhesive quality of the pad. If you are experiencing this, you can wipe the area with witch hazel and allow to dry prior to applying the pad. We tend to see this issue more as temperatures heat up.

Wash the Pads. Washing them with the SilcSkin Cleanser will remove the exfoliated skin cells which can interfere with the adhesive quality of the pad. You may air dry the pad, however it is better to dry it with a hair dryer to revive the adhesive.

Also, if you think the pad might have become contaminated with either a residue of soap, lotion's or sunscreen's it can be wiped down with rubbing alcohol (using a gauze or paper towel) to clean it. Also, the area where you wear the pad can be cleaned with Witch Hazel and allowed to dry prior to wearing the pad, this assures that no residue of product remains on the skin and also helps if there is perspiration.

Silicone is extremely expensive to produce, hence the high price. But we stand 100% behind our products and do everything to assure that they last as long as possible.